

Quick Release Tool (LLCR-K) Instructions for Use

This install tool is applicable for all devices using the **Spring Clamp** with trigger, including **BIRDFLAPPA**, **FLAGMARKA** and **LINZEBRA**.

- This product is to be used by authorised industry trained personnel only.
- The use of this product must adhere to appropriate work practises and or industry standards ensuring compliance to all Workplace Health and Safety Regulations.
- This product may only be installed onto an asset when the asset owner has approved of such installation.
- Failure to follow appropriate work practices and operational instructions or modifications to this equipment can result in product damage and or serious injury.
- These instructions are to be read in conjunction with the Balmoral Engineering terms and conditions published on our website.



Scan the QR code
Or
Click here to watch

Step 1 Assemble the Screw Install Tool (LLCR-K) to the Hot Stick



Quick Release Tool, Part No.: LLCR-K



Align the teeth and assemble the Hot Stick onto the Sunrise Fittings.

Step 2 Engage the Device to the Tool



Be aware the Strong Spring, wear protective gloves during the whole process.



2.1 Open the device as shown above until the device is locked by the trigger.



2.2 Affix the device on to the holder.

Warning: Be aware of the strong spring to avoid hurt fingers.

Step 3 Install the Device to Powerline



3.1 Slowly raise the device to the Powerline, rest the Bottom Clamp against the Line, and gently push the Hot Stick to release the trigger.



3.2 The installation is complete, push the Hot Stick up and then away from the device to remove the tool, to prevent the decices rotating.

For more product information please visit our website: www.balmoralengineering.com