

Instructions For Use

YSS-211-3-5



- This product is to be used by authorised industry trained personnel only.
- The use of this product must adhere to appropriate work practises and or industry standards ensuring compliance to all Workplace Health and Safety Regulations.
- This product may only be installed onto an asset when the asset owner has approved of such installation.
- Failure to follow appropriate work practices and operational instructions or modifications to this equipment can result in product damage and or serious injury.
- These instructions are to be read in conjunction with the Balmoral Engineering terms and conditions published on our website.

It is recommended that the **BALMORAL**™ LV Clamps should be cared for in the following manner:

Storage:

• To prevent premature wear of the **BALMORAL**TM LV Clamps, Store within a suitable carry bag during work

Note: other storage methods may be suitable, however, if these methods have not been approved by Balmoral, then the customer takes full responsibility for their suitability.

- We recommend that the BALMORAL[™] LV Clamps be stored in a clean ,temperature stable environment away from sharp objects, sunlight, ozone and steam.
- Kept clear of all oil based products and hydrocarbon derivatives.

Use:

- Prior to commencement of work, the **BALMORAL**TM LV Clamps should be visually inspected for any defects. Please refer to the section "Periodic Visual Inspection and Care".
- Should any item be found to have a defect, the item should be removed from service.
- Any item that becomes soiled or dirty should be cleaned.
- See below "Periodic Visual Inspection and Care" instructions for further directions on how to clean and inspect rescue kits.

Periodic Visual Inspection and Care:

• It is recommended that where it is possible or practical to do so, **BALMORAL**™ LV Clamps be periodically inspected, cleaned and then re-inspected. This periodic inspection is recommended to take place every 6 months and should be an adjunct not a replacement for the routine (prior to use) inspection.

To aid visual inspection, materials should be:

- Cleaned to remove grime and dirt which may otherwise hide potential defects.
- o Item removed from carry bag and placed on a table/workbench.
- If either component is found to be defective, the item should be removed from service.
- It is recommended that a mild detergent or specialised cleaner with a microfiber cloth are used to clean **BALMORAL**™ LV Clamps.
- Defects may take the form of embedded foreign objects, cuts, abrasions, tears, cracking, rust or any other form of aging or damage.

For further product information - Visit our website: