



Compiled/Updated	Approved	Issued Date	Revision
ZB	CD	5-8-25	5

Pole Top Rescue Kits Instructions For Use



- ***This product is to be used by authorised industry trained personnel only.***
- ***The use of this product must adhere to appropriate work practises and or industry standards ensuring compliance to all Workplace Health and Safety Regulations.***
- ***This product may only be installed onto an asset when the asset owner has approved of such installation.***
- ***Failure to follow appropriate work practices and operational instructions or modifications to this equipment can result in product damage and or serious injury.***
- ***These instructions are to be read in conjunction with the Balmoral Engineering terms and conditions published on our website.***

It is recommended that **BALMORAL™** Pole Top Rescue Kits should be cared for in the following manner:

Storage:

- To prevent premature wear of the rescue kit during work keep out of direct sunlight for long periods of time away from debris and objects that can slice or cut the Rescue kit.

Note: other storage methods may be suitable, however, if these methods have not been approved by Balmoral, then the customer takes full responsibility for their suitability.

- We recommend that Rescue kits be stored in a clean, temperature - stable environment away sunlight, ozone and steam.
- Kept clear of all oil-based products and hydrocarbon derivatives.

Use:

- Prior to commencement of work, Rescue kits should be visually inspected for any defects. Please refer to the section "Periodic Visual Inspection and Care".
- Should any item be found to have a defect, the rescue kit should be removed from service.
- Any component that becomes soiled or dirty should be cleaned.

Periodic Visual Inspection and Care:

- It is recommended that where it is possible or practical to do so, all rescue kits be periodically inspected, cleaned and then re-inspected. This periodic inspection is recommended to take place every 6 months and should be an adjunct not a replacement for the routine (prior to use) inspection.

To aid visual inspection, components should be:

- Removed from carry bag and placed on a table/workbench.
- Cleaned to remove grime and dirt which may otherwise hide potential defects.
- We recommend cleaning the external bag with either a mild detergent or Polywater® Rubber Goods Cleaner
- We recommend using a mild detergent with a microfiber towel for all components.
- If any component is found to be defective, the rescue kit should be removed from service.
- Each component of the rescue kit should be inspected for defects and relevant expiry/retest dates.
- Defects may take the form of embedded foreign objects, cuts, abrasions, tears, cracking, rust, fraying, battery leakage, loose threads, dullness of cutting tools and peeling.
- It is essential that components that expire or require retesting are inspected and removed after the expiry/retest date. Please note the date of manufacture of individual components may vary



Compiled/Updated	Approved	Issued Date	Revision
ZB	CD	5-8-25	5

Kit Components:

Item No.	Description	Kit Item Numbers				Image*
		11003	11003-4	11006	11019	
26011	Pole Top Rescue Box 350x340x340 PU- Orange- Latch closure				1 EA	
26013	Rescue Kit Bags & Storage, 385mm (L) x 350mm (H) x 180mm (W), PVC, Yellow, Velcro, Pole Top	1 EA	1 EA	1 EA		
/	Cardiopulmonary Resuscitation Card, 90mm x 220mm, folds down to 90mm x 55mm	1 EA	1 EA	1 EA	1 EA	
BB-O	Body Belt & Pole Strap- Orange/Black	1 EA	1 EA	1 EA	1 EA	
CC-60	Rescue Kit Accessories, Parrot Beak Cutter, 230mm (L), Cuts up to 70mm ² Cable, Red	1 EA	1 EA			
KNIFE-2	Rescue Kit Accessories, Webbing Cutter, 185mm (L) x 55mm (W), Red	1 EA				
GLO-RIG	Rescue Kit Accessories, Riggers Gloves, Large, Extended Cuff, Cowhide, Tan	1 PR	1 PR			
ANC-ST-4	Anchor Strap-1.6m-Orange-Rescue-Tie Back CW D	1 EA	1 EA			
ROPE-K-11-16	Rescue Kit Accessories, Kernmantle Rescue Rope, 16m (L) x 11mm (Dia), Double Action Snap Hook & Descent Device, AS 4142.3, Green	1 EA				
PLIERS-1	Combination Pliers-1000V	1 EA	1 EA			
RIG014YS11	LV Glove CL0 1000V 14" Yellow Str-Cuff Size 11	1 PR	1 PR	1 PR	1 PR	
26039	Knife CW Pouch Webbing Strap & D Ring			1 EA	1 EA	
ROPE-P-16-25	Polypropylene Film Rope Rescue- 25x16-Double/Snap Hook-Yellow			1 EA	1 EA	
ANC-ST-2	Descender link & Strap-1.8m- Orange-Recue-Descender – (Pretzel)			1 EA	1 EA	

* Product images displayed are representative only

For more product information please visit our website:
www.balmoralengineering.com