



Compiled/Updated	Approved	Issued Date	Revision
ZB	CD	27-10-25	3

Glove Talc Instructions For Use

- *This product is to be used by authorised industry trained personnel only.*
- *The use of this product must adhere to appropriate work practises and or industry standards ensuring compliance to all Workplace Health and Safety Regulations.*
- *This product may only be installed onto an asset when the asset owner has approved of such installation.*
- *Failure to follow appropriate work practices and operational instructions or modifications to this equipment can result in product damage and or serious injury.*
- *These instructions are to be read in conjunction with the Balmoral Engineering terms and conditions published on our website.*

It is recommended that **BALMORAL™** Glove Talc be cared for and used in the following manner:

Storage:

To prevent premature spoiling of the product, the following storage methods are recommended:

- Always store Talc with the lid closed in an upright position.
- Store in an enclosed space away from direct sunlight and steam.

Note: Other storage methods may be suitable, however, if these methods have not been approved by Balmoral, then the customer takes full responsibility for their suitability.

Use:

- To use the Glove Talc, twist the top cap and lightly apply the powder to the inside of the glove or sleeve.
- If talcum powder does not release from the container, refer to the section “Visual Inspection and Care”.

Visual Inspection and Care:

- To aid visual inspection, the external container of the Glove Talc should be cleaned to remove grime and dirt which may otherwise hide potential defects or interfere with the twist top cap or dispenser.
- It is recommended that a mild detergent with a microfiber cloth or rag are used to clean the external container.
- The Glove Talc itself should be inspected for any defects including lumps, inconsistency in the texture, discolouration or any other sign of aging. If this is found, the Glove Talc should be removed from service.
- It is recommended that talcum powder that is expired be removed from service.
- Please refer to the MSDS for further information about the product. It can be downloaded from the website here: << [Glove Talc MSDS](#)>>

For more product information please visit our website:
www.balmoralengineering.com