

## Cotton Gloves Instructions For Use

- *This product is to be used by authorised industry trained personnel only.*
- *The use of this product must adhere to appropriate work practises and or industry standards ensuring compliance to all Workplace Health and Safety Regulations.*
- *This product may only be installed onto an asset when the asset owner has approved of such installation.*
- *Failure to follow appropriate work practices and operational instructions or modifications to this equipment can result in product damage and or serious injury.*
- *These instructions are to be read in conjunction with the Balmoral Engineering terms and conditions published on our website.*

It is recommended that **BALMORAL™** Cotton Gloves should be cared for in the following manner:

### Storage:

- To prevent premature wear of the Cotton Gloves, they should be stored in a cool, dry area away from ozone and objects capable of cutting the material

Note: other storage methods may be suitable, however, if these methods have not been approved by Balmoral Engineering, then the customer takes full responsibility for their suitability.

### Use:

- Prior to the commencement of work, The Cotton Gloves should be visually inspected for any defects. Please refer to the section “Periodic Visual Inspection and Care” for further instructions.
- Should any item be found to have a defect, the Cotton Gloves should be removed from service.
- Any Cotton Gloves that becomes soiled or dirty should be cleaned or replaced.

### Periodic Visual Inspection and Care:

- It is recommended that where it is possible or practical to do so, all Cotton Gloves be periodically inspected, cleaned and then re-inspected. This periodic inspection is recommended to take place every 6 months and should be an adjunct inspection, not a replacement for the routine (prior to use) inspection.

To aid visual inspection, the Components should be cleaned to remove grime and dirt which may otherwise hide potential defects.

- We recommend washing the Cotton gloves on a gentle cycle in cold water in a washing machine and drying away from heat. If a washing machine is not available, soaking in warm water with detergent and rubbing together until clean, rinsing with warm water and drying away from heat.
- Defects may take the form of cuts, holes, excessive stretching and excessive discolouration.

**For more product information please visit our website:**

[www.balmoralengineering.com](http://www.balmoralengineering.com)